

4. Installation pictures




5. Attentions for installation

- Cut off the power and make sure the wall can burden the weight of the lamp before install .
- Make sure the lamp correctly install, in case of the lamp's dropping down.
- Don't use the lamp in the area with aggressive gas.
- Don't cover the lamp with anything ,which is harm for heat dissipation.
- Be careful and connect the group line well.
- Products faults caused by separating, remodeling, or incorrectly instruction are not in the warranty area.


3. Instruction of installation

1




Using the screws to install the power supply box onto the solid wall

2




Open the wire-conecting,connect the input wire of LED driver with the AC input,and then close the box.

3



Thrust the heat sink body into the two holes.

4



Closing the body using screws and tighten them.

Typical LED Wall Pack Instruction Manual



1. Application

Plant, Stadium, Industrial Lighting, Architechural Lightng, etc.

2. Features

(1) Including series patent .Unique funnel heat sinker, Making the lamp better for heat dissipation. Fresnel teeth design for PC reflector, which is suitable for wall light distribution.

(2) The LED driver and LED light source are separate, which is convenient for install and assemble.

(3) Waterproof for outdoor using